

Tighten all 4 flathead screws with large flathead screwdriver to ensure wires are tightly fit.

